

INSTALL INSTRUCTIONS

REAR BUMPER MODEL 2

(120109-1-K)

REQUIRED MATERIALS

4 ct.

1/2"-13x1-1/2" Bolts

Part Number: 120113-1



4 ct.

Washers

Part Number: 120012-1



1 ct.

Bumper

Part Number: 120109-1



BEFORE INSTALLATION

Make sure bumper has been cleaned and oil is removed so the bumper can be painted before installation.

STEP 1

Align bumper with rear of truck. Make sure you have all the necessary hardware nearby.



STEP 2

Slide bumper into factory mounting holes in the frame rail.



INSTALL INSTRUCTIONS (CONT'D.)


STEP 3

Put provided washers on bolts and slide bolts through aligned holes. Leave bolts loose so bumper can be adjusted.



STEP 4

Adjust bumper so it is even and tighten the bolts.



INSTALLED PHOTOS

