2007-20XX TOYOTA TUNDRA CREW MAX BED ACCESS, 5.0' BED

RUNNING BOARD INSTALLATION INSTRUCTIONS



SAFETY

Know safety, no injury. Know injury, no safety. ~Author Unknown If there are any questions, call 1-855-HHTOUGH

• READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION

- o FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
- WEAR APPROPRIATE EYE PROTECTION
- EXERCISE CARE WHEN LIFTING COMPONENTS
- USE APPROPRIATE TORQUE FOR BOLTS
- BLUE THREAD LOCKING COMPOUND IS RECOMMENDED ON ALL BOLTS
 - O SUGGESTED TORQUE VALUES FOR STEEL GRADE SAE 5 BOLTS

BOLT DIAMETER (INCH)	TREADS PER INCH	TORQUE (POUND-FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3∕4	10	200
7/8	9	302
1	8	466

Rev 00 4/20/18 Page 1



I. PARTS LIST

QUANTITY	PART NUMBER	DESCRIPTION
1	60P-56-0263	LEFT RUNNING BOARDS
1	60P-56-0264	RIGHT RUNNING BOARDS
1	60K-56-0075	HARDWARE KIT #75

II. TOOL LIST

- 1. A good friend
- 2. Basic tool kit
- 3. 13mm socket

III. VEHICLE PREPARATION

1. Remove plastic plugs from threaded inserts in body under doors. There are 4 sets of two.




2. Using M8 bolts from hardware kit #75, Thread bolts in and out of inserts to verify threads are clean of debris.

Rev 00 4/20/18 Page 2



IV. RUNNING BOARD INSTALLATION

1. Identify the left running board. It will have a bottle opener (arrow) on the left side.



- 2. Have a good friend help you hold the running board up to the truck.
- 3. Using hardware kit #75, use one bolt, one flat washer, and one lock washer for each threaded insert.
- 4. Using a 13mm socket, tighten hardware. Installation is now complete. Follow the same procedure for the right side of the vehicle.

Congratulations! Your installation is now complete. Thank you for your purchase.

Rev 00 4/20/18 Page 3