

2007-2016 JEEP JK

20" LIGHT BAR HOOD MOUNT INSTALLATION INSTRUCTIONS



SAFETY

Know safety, no injury. Know injury, no safety. ~Author Unknown

If there are any questions, call 1-855-HHTOUGH

- **READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION**
 - FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
 - WEAR APPROPRIATE EYE PROTECTION
 - EXERCISE CARE WHEN LIFTING COMPONENTS
 - USE APPROPRIATE TORQUE FOR BOLTS

SUGGESTED TORQUE VALUES FOR STEEL GRADE SAE 5 BOLTS

BOLT DIAMETER (INCH)	TREADS PER INCH	TORQUE (POUND-FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3/4	10	200
7/8	9	302
1	8	466



2007-2016 Jeep JK

I. PARTS LIST

<u>QUANTITY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>CHECKOFF</u>
1	601-56-1314	RIGHT 20" LIGHT BAR HOOD MOUNT	
1	601-56-1315	LEFT 20" LIGHT BAR HOOD MOUNT	
4	319-12-0016	TORX 40 PAN HEAD BOLT	
4	601-56-0836	NYLON SPACER	

II. TOOL LIST

1. Basic tool set
2. Torx 40 socket
3. Torx 50 socket

III. REMOVAL OF OEM BOLTS

1. Using a Torx 50 socket remove both the bolts from each hood latch



IV. **INSTALATION OF LIGHT BAR HOOD MOUNT**

1. Place a nylon spacer over each bolt hole
2. Place the LIGHT BAR HOOD MOUNT on top of the spacers



3. Using a Torx 40 socket place provided bolts 75% of the way in hood latch



4. Repeat steps 1-3 for the other side



5. Install light bar onto LIGHT BAR HOOD MOUNT according to its instructions
6. Finish by centering the light bar and fully tightening the Torx 40 bolts





2007-2016 Jeep JK



Congratulations! Your hammerhead 20" light bar hood mount installation is now complete.

Thank you for your purchase.