

2007-2017 JEEP JK

HAMMERHEAD FOOT PEG INSTALLATION INSTRUCTIONS



SAFETY

Know safety, no injury. Know injury, no safety. ~Author Unknown

If there are any questions, call 1-855-HHTOUGH

- **READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION**
 - FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
 - WEAR APPROPRIATE EYE PROTECTION
 - EXERCISE CARE WHEN LIFTING COMPONENTS
 - USE APPROPRIATE TORQUE FOR BOLTS

SUGGESTED TORQUE VALUES FOR STEEL GRADE SAE 5 BOLTS

BOLT DIAMETER (INCH)	TREADS PER INCH	TORQUE (POUND-FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3/4	10	200
7/8	9	302
1	8	466



2007-2017 Jeep JK

I. PARTS LIST

<u>QUANTITY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>CHECKOFF</u>
2	601-56-3747	LEFT FOOT PEG	
2	601-56-3748	RIGHT FOOT PEG	
1	60K-56-0101	HARDWARE KIT #105	

II. HARDWARE KIT #82

<u>QUANTITY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>CHECKOFF</u>
2	302-02-0098	0.375x16x2.00 BOLT HH 05 ZN	

III. TOOL LIST

1. Basic tool set
2. 9/16" wrench

IV. INSTALATION OF HAMMERHEAD FOOT PEGS

1. Place the provided rubber caps on the lip of the HAMMERHEAD FOOT PEG



2. Remove door. Use a 9/16" wrench to install the HAMMERHEAD FOOT PEG on the lower door hinge with the provided bolt. Do for both sides

WARNING: Placing limbs outside the vehicle can be a safety hazard. Do so at own risk.



2007-2017 Jeep JK



Congratulations! Your Hammerhead Foot Peg installation is now complete.

Thank you for your purchase.