



07- JEEP JK

NOTE: All surfaces should be clean and dry before attaching brackets.

1. Place wheels in straight forward position.
2. Using a 18mm wrench remove the stock nut and bolt from bracket A. Retain hardware for later use.
3. Using a 18mm wrench remove the nut from bracket B. Retain the stock nut for later use.
4. Remove the stock steering stabilizer.
5. Using a 13mm wrench loosen the u-bolts holding bracket C. Move the bracket $\frac{3}{4}$ " toward the passengers side. Tighten u-bolts.
6. Insert sleeve from kit bag into the rod end of the 721063 cylinder.
7. Place rod end on cylinder in bracket A, insert factory bolt and nut.
8. Extend stabilizer to bracket B, insert on stud and replace the factory nut.
6. Turn wheels fully to the right and left making sure that no interference occurs and that wheel stops are fully contacted.
7. Recheck all nuts for tightness before releasing installation.
8. Periodically inspect the assembly for tightness.

BOX CONTENT

One Stabilizer cylinder
One Installation Instruction sheet
One Kit Bag

POLY BAG #1

1- Sleeve

CAUTION: Any and all warranties including but not limited to any express warranties, implied warranty of merchantability, or implied warranty of fitness for a particular purpose shall not apply to any product altered in any way outside the premises of the manufacturer or to any product which is not installed in accordance with the written instructions provided by the manufacturer for installation of the product.