

ROUGH COUNTRY

SUSPENSION SYSTEMS®

Can-Am Defender 12" LED Bumper Mount

Thank you for choosing Rough Country for all your off road needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @ 1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products.

Tools Needed:

- 13mm Socket
- 13mm Wrench



Kit Contents:

2- 12" LED Mounting Brackets

1- 71001BAG1

2- 8mm x 20mm Light Mounting Bolts

2- 8mm Flat Washers

2- 8mm Nylock Nuts

1-12" Rough Country LED Light:

1- LED Light Wiring Harness

1- 12" LED Light Cover

1- 5mm Allen Wrench

1- 6mm Allen Wrench

INSTALLATION INSTRUCTIONS

1. Install the supplied light brackets using the supplied 8mm bolts, washers, and nuts. **See Photo 1.**
2. Using the supplied hardware, mount the 12" light to the mounting brackets. Tighten using the supplied Allen wrench. **See Photo 2.**



Photo 1



Photo 2

3. Tighten the light mounting brackets using 13mm wrenches.
4. Wire the light according to the supplied instructions.

Thank You for choosing Rough Country for your lighting needs!!!

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

